

## Instructions for fastening marking head - column



- A Replace the marking head.
- B Tighten the screw < **1** > on the left and right side.
- C Screw the pressure regulator with screws < **2** >.

k:\bedienungsanltg\nadelpräger\mk3\englisch\neu\fastening-head-column\_gb.doc

