

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
<i>Board</i>	B01.0	Power Board	66.SB010	S	S	S			
	B02.0	Power Supply	66.SB020	S	S	S			
	B03.0	PCB Logic Board	66.SB030	S	S	S			
	B04.1	Fan	66.SB040	W	W	W			
	B04.2	Fan	66.SB040	W	W	W			
	B05.0	Eprom	66.SB055.52	S	S	S			
	B05.1	Eprom	66.SB057.04	S	S	S			
	B05.2	Eprom	66.SB057.10	S	S	S			
	B06.0	Battery	66.SB060	S	S	S			
<i>Electronics</i>	E01.1	Engine Y-Axis	66.SE011	W	W	W			
	E01.2	Engine X-Axis	66.SE011	W	W	W			
	E02.0	Connection circuit board	66.SE020		S	S			
	E02.1	Connection circuit board	66.SE021	S					
	E03.1	Sensor M8x1 with cable	66.SE030	S	S	S			
	E03.2	Sensor M8x1 with cable	66.SE030	S	S	S			
	E04.1	Nut DIN 934-M8x1	0439.081	S	S	S			
	E04.2	Nut DIN 934-M8x1	0439.081	S	S	S			
	E06.1	Rubberbuffer ø9x12 ; bothside M4x12	66.SE061	S	S				
	E06.2	Rubberbuffer ø9x12 ; bothside M4x12	66.SE061	S	S				
	E06.3	Rubberbuffer ø9x12 ; bothside M4x12	66.SE061	S	S				
	E06.4	Rubberbuffer ø9x12 ; bothside M4x12	66.SE061	S	S				
	E06.5	Spacer pin SW8x12; M4	66.SR091			S			
	E06.6	Spacer pin SW8x12; M4	66.SR091			S			
	E06.7	Spacer pin SW8x12; M4	66.SR091			S			
	E06.8	Spacer pin SW8x12; M4	66.SR091			S			
	E07.1	Fan washer DIN 6798-A 4,3	6798.043	S	S				
	E07.2	Fan washer DIN 6798-A 4,3	6798.043	S	S				
	E07.3	Fan washer DIN 6798-A 4,3	6798.043	S	S				
	E07.4	Fan washer DIN 6798-A 4,3	6798.043	S	S				
	E08.1	Nut DIN-934-M4	0934.04	S	S				
	E08.2	Nut DIN-934-M4	0934.04	S	S				
	E08.3	Nut DIN-934-M4	0934.04	S	S				

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
	E08.4	Nut DIN-934-M4	0934.04	S	S				
	E08.5	Fillister-head screw DIN-7985-M 4x10	7985.04010			S			
	E08.6	Fillister-head screw DIN-7985-M 4x10	7985.04010			S			
	E08.7	Fillister-head screw DIN-7985-M 4x10	7985.04010			S			
	E08.8	Fillister-head screw DIN-7985-M 4x10	7985.04010			S			
	E09.1	Cylinder head screw DIN-912-M4x16	0912.04016	S	S	S			
	E09.2	Cylinder head screw DIN-912-M4x16	0912.04016	S	S	S			
	E09.3	Cylinder head screw DIN-912-M4x16	0912.04016	S	S	S			
	E09.4	Cylinder head screw DIN-912-M4x16	0912.04016	S	S	S			
	E09.5	Cylinder head screw DIN-912-M4x16	0912.04016	S	S	S			
	E09.6	Cylinder head screw DIN-912-M4x16	0912.04016	S	S	S			
	E09.7	Cylinder head screw DIN-912-M4x16	0912.04016	S	S	S			
	E09.8	Cylinder head screw DIN-912-M4x16	0912.04016	S	S	S			
	E10.1	Washer DIN 925-B 4,3	0125.043	S	S	S			
	E10.2	Washer DIN 925-B 4,3	0125.043	S	S	S			
	E10.3	Washer DIN 925-B 4,3	0125.043	S	S	S			
	E10.4	Washer DIN 925-B 4,3	0125.043	S	S	S			
	E10.5	Washer DIN 925-B 4,3	0125.043	S	S	S			
	E10.6	Washer DIN 925-B 4,3	0125.043	S	S	S			
	E10.7	Washer DIN 925-B 4,3	0125.043	S	S	S			
	E10.8	Washer DIN 925-B 4,3	0125.043	S	S	S			
	E11.1	Fan washer DIN 6798-A 4,3	6798.043	S	S	S			
	E11.2	Fan washer DIN 6798-A 4,3	6798.043	S	S	S			
	E11.3	Fan washer DIN 6798-A 4,3	6798.043	S	S	S			
	E11.4	Fan washer DIN 6798-A 4,3	6798.043	S	S	S			
	E11.5	Fan washer DIN 6798-A 4,3	6798.043	S	S	S			
	E11.6	Fan washer DIN 6798-A 4,3	6798.043	S	S	S			
	E11.7	Fan washer DIN 6798-A 4,3	6798.043	S	S	S			
	E11.8	Fan washer DIN 6798-A 4,3	6798.043	S	S	S			
	E12.1	Nut DIN-934-M4	0934.04	S	S	S			
	E12.2	Nut DIN-934-M4	0934.04	S	S	S			
	E12.3	Nut DIN-934-M4	0934.04	S	S	S			
	E12.4	Nut DIN-934-M4	0934.04	S	S	S			
	E12.5	Nut DIN-934-M4	0934.04	S	S	S			

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
	E12.6	Nut DIN-934-M4	0934.04	S	S	S			
	E12.7	Nut DIN-934-M4	0934.04	S	S	S			
	E12.8	Nut DIN-934-M4	0934.04	S	S	S			
	E15.0	Sicherheitsschalter (Öffner)	66.SE150		S				
	E15.1	Sicherheitsschalter (Schließer)	66.SE151	S					
<i>Housing</i>	G01.0	Cover plate	66.SG010		S				
	G01.2	Cover plate	66.SG012			S			
	G01.3	Cover plate	66.SG013	S					
	G02.0	Covering	66.SG020		S				
	G02.1	Covering	66.SG021			S			
	G02.2	Covering	66.SG022	S					
	G03.0	Sliding plate 1	66.SG1030		S				
	G04.0	Sliding plate 2	66.SG1040		S				
	G05.0	Sliding plate 3	66.SG1050		S				
	G08.0	Protection plate	66.SG1080		S				
		Sliding plate-set cpl. G03.0 - G08.0	66.TAP-T1		S				
	G03.1	Sliding plate 1	66.SG2031			S			
	G04.1	Sliding plate 2	66.SG2041			S			
	G05.1	Sliding plate 3	66.SG2051			S			
	G06.1	Sliding plate 4	66.SG2061			S			
	G07.1	Sliding plate 5	66.SG2071			S			
	G08.1	Protection plate	66.SG2081			S			
		Sliding plate-set cpl. G03.1 - G08.1	66.TAP-T2			S			
	G03.2	Sliding plate 1	66.SG3032	S					
	G04.2	Sliding plate 2	66.SG3042	S					
	G05.2	Sliding plate 3	66.SG3052	S					
	G08.2	Protection plate	66.SG3082	S					
		Sliding plate-set cpl. G03.2 - G08.2	66.TAP-T8	S					
	G09.1	Flat screw w. ISK DIN-7991-M 4x10	7991.04010	S	S	S			
	G09.2	Flat screw w. ISK DIN-7991-M 4x11	7991.04010	S	S	S			
	G09.3	Flat screw w. ISK DIN-7991-M 4x12	7991.04010	S	S	S			
	G09.4	Flat screw w. ISK DIN-7991-M 4x13	7991.04010	S	S	S			
	G10.1	Cylinder head screw DIN-912-M 4x3	0912.04010	S	S	S			

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
	G10.2	Cylinder head screw DIN-912-M 4x4	0912.04010	S	S	S			
	G10.3	Cylinder head screw DIN-912-M 4x5	0912.04010	S	S	S			
	G10.4	Cylinder head screw DIN-912-M 4x6	0912.04010	S	S	S			
	G10.5	Cylinder head screw DIN-912-M 4x7	0912.04010	S	S	S			
	G10.6	Cylinder head screw DIN-912-M 4x8	0912.04010	S	S	S			
	G10.7	Cylinder head screw DIN-912-M 4x9	0912.04010	S	S	S			
	G10.8	Cylinder head screw DIN-912-M 4x10	0912.04010	S	S	S			
	G11.1	Washer DIN 925-B 4,3	0125.043	S	S	S			
	G11.2	Washer DIN 925-B 4,3	0125.043	S	S	S			
	G11.3	Washer DIN 925-B 4,3	0125.043	S	S	S			
	G11.4	Washer DIN 925-B 4,3	0125.043	S	S	S			
	G11.5	Washer DIN 925-B 4,3	0125.043	S	S	S			
	G11.6	Washer DIN 925-B 4,3	0125.043	S	S	S			
	G11.7	Washer DIN 925-B 4,3	0125.043	S	S	S			
	G11.8	Washer DIN 925-B 4,3	0125.043	S	S	S			
	G10.1	Flat screw DIN-7991-M4x10	7991.04010	S	S	S			
	G10.2	Flat screw DIN-7991-M4x10	7991.04010	S	S	S			
	G10.3	Flat screw DIN-7991-M4x10	7991.04010	S	S	S			
	G10.4	Flat screw DIN-7991-M4x10	7991.04010	S	S	S			

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
<i>Pneumatics</i>	P01.0	Cross block	66.SP010		S	S			
	P01.1	Cross block	66.SP011	S					
	P02.1	Bearing case form V	66.SP022		W	W			
	P02.2	Bearing case form V	66.SP022		W	W			
	P02.3	Bearing case form V	66.SP022		W	W			
	P02.4	Bearing case form V	66.SP022		W	W			
	P02.5	Bearing case form J	66.SP025	W					
	P02.6	Bearing case form J	66.SP025	W					
	P02.7	Bearing case form J	66.SP025	W					
	P02.8	Bearing case form J	66.SP025	W					
	P03.0	Plug thread joint QS-1/8-8	66.SP030		S				
	P03.1	Plug thread joint QSL-1/8-8	66.SP031	S		S			
	P04.0	Marking valve	66.SP040	W	W	W			
	P05.0	Filter with pressure reducer and manometer	66.SP050	W	W	W			
	P06.0	Tube 8; 180mm long	66.SP060		W				
	P06.1	Tube 8; 140mm long	66.SP060			W			
	P06.2	Tube 8; 100mm long	66.SP060	W					
	P07.0	Tube PUN-8; 500mm long	34.156	S	S	S			
	P08.1	Cylinder head screw DIN-912-M3x8	0912.03008	S	S	S			
	P08.2	Cylinder head screw DIN-912-M3x8	0912.03008	S	S	S			
	P08.3	Cylinder head screw DIN-912-M3x8	0912.03008	S	S	S			
	P10.0	NBG Pick-up	66.SP100		S	S			
	P10.1	NBG Pick-up	66.SP101	S					
	P11.1	Cylinder head screw DIN-912-M 6x20	0912.06020		S	S			
	P11.2	Cylinder head screw DIN-912-M 3x18	0912.03018	S					
	P11.3	Cylinder head screw DIN-912-M 3x18	0912.03018	S					
	P12.0	O-Ring ø5x1,78mm	66.96008.0S	W					
	P13.0	O-Ring ø19x3,5mm	66.96007.0S	W	W	W			

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
<i>Frame</i>	R01.0	Basic body	66.SR010		S				
	R01.1	Basic body	66.SR011			S			
	R01.2	Basic body	66.SR012	S					
	R02.0	Rack compl.	66.SR020						
	R03.0	Side part right	66.SR030		S				
	R03.1	Side part right	66.SR031			S			
	R03.2	Side part right	66.SR032	S					
	R04.0	Side part left	66.SR040		S				
	R04.1	Side part left	66.SR041			S			
	R04.2	Side part left	66.SR042	S					
	R05.0	Front plate	66.SR050		S				
	R05.1	Front plate	66.SR051			S			
	R05.2	Front plate	66.SR052	S					
	R06.0	Rear plate	66.SR060		S				
	R06.1	Rear plate	66.SR061			S			
	R07.0	Stop block	66.SR070		S				
	R08.0	Engine flange	66.SR080		S	S			
	R09.1	Spacer pin SW8x12; M4	66.SR091		S	S			
	R09.2	Spacer pin SW8x12; M4	66.SR091		S	S			
	R10.1	Spacer pin SW8x23; M4	66.SR101		S	S			
	R10.2	Spacer pin SW8x23; M4	66.SR101		S	S			
	R12.0	Mounting plate	66.SR120		S				
	R12.1	Mounting plate	66.SR121			S			
	R12.2	Mounting plate	66.SR122	S					
	R13.1	Cylinder head screw DIN-912-M5x12	0912.05.012	S	S	S			
	R13.2	Cylinder head screw DIN-912-M5x12	0912.05.012	S	S	S			
	R13.3	Cylinder head screw DIN-912-M5x12	0912.05.012	S	S	S			
	R14.1	Cylinder head screw DIN-912-M5x12	0912.05.012	S	S	S			
	R14.2	Cylinder head screw DIN-912-M5x12	0912.05.012	S	S	S			
	R14.3	Cylinder head screw DIN-912-M5x12	0912.05.012	S	S	S			

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
<i>Needle grp.</i>	W301.S	Needle holder	66.60000.3S				S	S	
	W302.S	Replacement needle ø3	66.64060.3S				W	W	
	W303.S	Piston	66.60005.3S				W		
	W303.L	Piston	66.60003.3S					W	
	W304	Thread pin DIN-915-M6x10	0915.06010				S	S	
	W305.S	Spring Di 9,1x1,1x26mm	66.96000.0S				W		
	W305.L	Spring Di 9,0x0,9x35mm	66.96000.1S					W	
	W306.S	O-ring ø14x2,5mm	66.96004.0S				W	W	
	W307.S	O-ring ø9,25x1,78mm	66.96005.0S				W	W	
	W308	Washer DIN 9021-A 4,3	0125.064				S	S	
	W309.S	O-ring ø7,5x1,7mm	66.96002.0S				W	W	
	W601.S	Needle holder	66.60000.6S						S
	W602.S	Replacement needle ø6	66.64060.6S						W
	W603.S	Piston	66.60005.6S						W
	W604	Bolt thread DIN-913-M6x10-A2	0913.06010						S
	W605.S	Spring Di 9,1x1,1x26mm	66.96000.0S						W
	W606.S	O-ring ø26x2,5mm	66.96006.0S						W
	W607.S	O-ring ø19x3,5mm	66.96007.0S						W

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
Drive - X	X01.0	Drive shaft	66.SX010		W				
	X01.1	Drive shaft	66.SX011	W					
	X01.2	Drive shaft	66.SX012			W			
	X02.1	Moving shaft	66.SX021		W				
	X02.2	Moving shaft	66.SX022	W					
	X02.3	Moving shaft	66.SX023			W			
	X03.0	Bearing shaft	66.SX030		W				
	X03.1	Bearing shaft	66.SX031	W					
	X03.2	Bearing shaft	66.SX032			W			
	X04.1	Mounting block - X	66.SX041		S	S			
	X04.2	Mounting block - X	66.SX041		S	S			
	X04.3	Mounting block - X	66.SX043	S					
	X04.4	Mounting block - X	66.SX043	S					
	X05.1	Mounting roll 12T5/10-0	66.SX051		S	S			
	X05.2	Mounting roll 12T5/10-0	66.SX051		S	S			
	X05.3	Mounting roll 12T5/10-0	66.SX051		S	S			
	X05.4	Mounting roll 12T5/10-0	66.SX051		S	S			
	X05.5	Mounting roll 9T2,5/16-0	66.SX055	S					
	X05.6	Mounting roll 9T2,5/16-0	66.SX055	S					
	X05.7	Mounting roll 9T2,5/16-0	66.SX055	S					
	X05.8	Mounting roll 9T2,5/16-0	66.SX055	S					
	X06.1	Toothed belt washer D5; 15T ; W15	66.SX061		S	S			
	X06.2	Toothed belt washer D5; 15T ; W15	66.SX061		S	S			
	X06.3	Toothed belt washer D2,5; 20T ; W10	66.SX063	S					
	X06.4	Toothed belt washer D2,5; 20T ; W10	66.SX063	S					
	X07.1	Belt case	66.SX071		S	S			
	X07.2	Belt case	66.SX071		S	S			
	X07.3	Toothed belt washer D2,5; 20T ; W10	66.SX063	S					
	X07.4	Toothed belt washer D2,5; 20T ; W10	66.SX063	S					
	X08.0	Toothed belt washer D5; 30T ; W15	66.SX080		S	S			
	X08.1	Toothed belt washer D2,5; 40T ; W10	66.SX081	S					
	X09.0	Toothed belt washer D5; 10T ; W15	66.SX090		S	S			
	X09.1	Toothed belt washer D2,5; 10T ; W10	66.SX091	S					

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
	X10.0	Toothed belt D5; 10mm; 260mm closed	66.SX100		W	W			
	X10.1	Toothed belt D2,5; 7,5mm; 380mm closed	66.SX101	W					
	X11.1	Toothed belt D5; 10mm; 510mm long	66.SX111.051		W				
	X11.2	Toothed belt D5; 10mm; 510mm long	66.SX111.051		W				
	X11.3	Toothed belt D2,5; 7,5mm; 380mm long	66.SX101	W					
	X11.4	Toothed belt D2,5; 7,5mm; 380mm long	66.SX101	W					
	X11.5	Toothed belt D5; 10mm; 710mm long	66.SX111.071			W			
	X11.6	Toothed belt D5; 10mm; 710mm long	66.SX111.071			W			
	X12.1	Bearing case form J	66.SX121		W	W			
	X12.2	Bearing case form J	66.SX121		W	W			
	X12.3	Bearing case form J	66.SX121		W	W			
	X12.4	Bearing case form J	66.SX121		W	W			
	X12.5	Bearing case form J	66.SX125	W					
	X12.6	Bearing case form J	66.SX125	W					
	X12.7	Bearing case form J	66.SX125	W					
	X12.8	Bearing case form J	66.SX125	W					
	X13.1	Needle bushing (HK 1210 B)	66.SX131		W	W			
	X13.2	Needle bushing (HK 1210 B)	66.SX131		W	W			
	X13.3	Needle bushing (HK 1210 B)	66.SX131		W	W			
	X13.4	Needle bushing (HK 1210 B)	66.SX131		W	W			
	X13.5	Needle bushing (BK 0810)	66.SX135	W					
	X13.6	Needle bushing (BK 0810)	66.SX135	W					
	X13.7	Needle bushing (BK 0810)	66.SX135	W					
	X13.8	Needle bushing (HK 0810)	66.SX138	W					
	X14.1	Cylinder head screw DIN-912-M5x12	0912.05012		S	S			
	X14.2	Cylinder head screw DIN-912-M5x12	0912.05012		S	S			
	X14.3	Cylinder head screw DIN-912-M5x12	0912.05012		S	S			
	X14.4	Cylinder head screw DIN-912-M5x12	0912.05012		S	S			
	X14.5	Cylinder head screw DIN-912-M4x12	0912.04012	S					
	X14.6	Cylinder head screw DIN-912-M4x12	0912.04012	S					
	X14.7	Cylinder head screw DIN-912-M4x12	0912.04012	S					
	X14.8	Cylinder head screw DIN-912-M4x12	0912.04012	S					
	X15.1	Cylinder head screw DIN-912-M5x12	0912.05012		S				
	X15.2	Cylinder head screw DIN-912-M5x12	0912.05012		S				

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
	X15.3	Cylinder head screw DIN-912-M4x12	0912.04012	S					
	X15.4	Cylinder head screw DIN-912-M4x12	0912.04012	S					
	X16.1	Washer DIN 9021-A 5,3	9021.053		S				
	X16.2	Washer DIN 9021-A 5,3	9021.053		S				
	X16.3	Washer DIN 9021-A 4,3	9021.043	S					
	X16.4	Washer DIN 9021-A 4,3	9021.043	S					
	X19.1	Thread pin DIN-916-M4x16	0916.04016		S	S			
	X19.2	Thread pin DIN-916-M4x16	0916.04016		S	S			
	X19.3	Thread pin DIN-916-M4x16	0916.04016	S					
	X19.4	Thread pin DIN-916-M4x16	0916.04016	S					
	X20.0	Thread pin DIN-916-M4x5	0916.04005		S	S			
	X20.1	Instep case ISO 8752 2,5x5	8752.02505	S					
	X20.2	Instep case ISO 8752 2,5x5	8752.02505	S					
	X21.1	Thread pin DIN-915-M4x5	0916.04005		S	S			
	X21.2	Thread pin DIN-915-M4x5	0916.04005		S	S			
	X21.3	Instep case ISO 8752 2,5x5	8752.02505	S					
	X21.4	Instep case ISO 8752 2,5x5	8752.02505	S					
	X22.1	Locking washer DIN 6799-10	6799.10		S	S			
	X22.2	Locking washer DIN 6799-10	6799.10		S	S			
	X22.3	Locking washer DIN 6799-7	6799.07	S					
	X23.1	Locking washer DIN 6799-9	6799.09		S	S			
	X23.2	Locking washer DIN 6799-9	6799.09		S	S			
Drive - Y	Y01.0	Drive shaft	66.SY010		W				
	Y01.1	Drive shaft	66.SY011	W					
	Y01.2	Drive shaft	66.SY012			W			
	Y02.1	Moving shaft	66.SY021		W				
	Y02.2	Moving shaft	66.SY022	W					
	Y02.3	Moving shaft	66.SY023			W			
	Y03.0	Bearing shaft	66.SY030		W				
	Y03.1	Bearing shaft	66.SY031	W					
	Y03.2	Bearing shaft	66.SY032			W			
	Y04.1	Mounting block - Y	66.SY041		S	S			
	Y04.2	Mounting block - Y	66.SY041		S	S			

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
	Y04.3	Mounting block - Y	66.SY043	S					
	Y04.4	Mounting block - Y	66.SY043	S					
	Y05.1	Mounting roll 12D5 / 10-0	66.SX051		S	S			
	Y05.2	Mounting roll 12D5 / 10-0	66.SX051		S	S			
	Y05.3	Mounting roll 12D5 / 10-0	66.SX051		S	S			
	Y05.4	Mounting roll 12D5 / 10-0	66.SX051		S	S			
	Y05.5	Mounting roll 9D2,5 / 16-0	66.SX055	S					
	Y05.6	Mounting roll 9D2,5 / 16-0	66.SX055	S					
	Y05.7	Mounting roll 9D2,5 / 16-0	66.SX055	S					
	Y05.8	Mounting roll 9D2,5 / 16-0	66.SX055	S					
	Y06.1	Toothed belt washer D5; 15T ; W15	66.SX061		S	S			
	Y06.2	Toothed belt washer D5; 15T ; W15	66.SX061		S	S			
	Y06.3	Toothed belt washer D2,5; 20T ; W10	66.SX063	S					
	Y06.4	Toothed belt washer D2,5; 20T ; W10	66.SX063	S					
	Y07.1	Belt case	66.SX071		S	S			
	Y07.2	Belt case	66.SX071		S	S			
	Y07.3	Toothed belt washer D2,5; 20T ; W10	66.SX063	S					
	Y07.4	Toothed belt washer D2,5; 20T ; W10	66.SX063	S					
	Y08.0	Toothed belt washer D5; 30T ; W15	66.SX080		S	S			
	Y08.1	Toothed belt washer D2,5; 40T ; W10	66.SX081	S					
	Y09.0	Toothed belt washer D5; 10T ; W15	66.SX090		S	S			
	Y09.1	Toothed belt washer D2,5; 10T ; W10	66.SX091	S					
	Y10.0	Toothed belt D5; 10mm; 260mm closed	66.SX100		W	W			
	Y10.1	Toothed belt D2,5; 7,5mm; 265mm closed	66.SY101	W					
	Y11.1	Toothed belt D5; 10mm; 410mm long	66.SX111.041		W				
	Y11.2	Toothed belt D5; 10mm; 410mm long	66.SX111.041		W				
	Y11.3	Toothed belt D2,5; 7,5mm; 265mm long	66.SY101	W					
	Y11.4	Toothed belt D2,5; 7,5mm; 265mm long	66.SY101	W					
	Y11.5	Toothed belt D5; 10mm; 660mm long	66.SX111.066			W			
	Y11.6	Toothed belt D5; 10mm; 660mm long	66.SX111.066			W			
	Y12.1	Bearing case form J	66.SX121		W	W			
	Y12.2	Bearing case form J	66.SX121		W	W			
	Y12.3	Bearing case form J	66.SX121		W	W			
	Y12.4	Bearing case form J	66.SX121		W	W			

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
	Y12.5	Bearing case form J	66.SX125	W					
	Y12.6	Bearing case form J	66.SX125	W					
	Y12.7	Bearing case form J	66.SX125	W					
	Y12.8	Bearing case form J	66.SX125	W					
	Y13.1	Needle bushing (HK 1210 B)	66.SX131		W	W			
	Y13.2	Needle bushing (HK 1210 B)	66.SX131		W	W			
	Y13.3	Needle bushing (HK 1210 B)	66.SX131		W	W			
	Y13.4	Needle bushing (HK 1210 B)	66.SX131		W	W			
	Y13.5	Needle bushing (BK 0810)	66.SX135	W					
	Y13.6	Needle bushing (BK 0810)	66.SX135	W					
	Y13.7	Needle bushing (BK 0810)	66.SX135	W					
	Y13.8	Needle bushing (HK 0810)	66.SX138	W					
	Y14.1	Cylinder head screw DIN-912-M5x12	0912.05012		S	S			
	Y14.2	Cylinder head screw DIN-912-M5x12	0912.05012		S	S			
	Y14.3	Cylinder head screw DIN-912-M5x12	0912.05012		S	S			
	Y14.4	Cylinder head screw DIN-912-M5x12	0912.05012		S	S			
	Y14.5	Cylinder head screw DIN-912-M4x12	0912.04012	S					
	Y14.6	Cylinder head screw DIN-912-M4x12	0912.04012	S					
	Y14.7	Cylinder head screw DIN-912-M4x12	0912.04012	S					
	Y14.8	Cylinder head screw DIN-912-M4x12	0912.04012	S					
	Y15.3	Cylinder head screw DIN-912-M4x12	0912.04012	S					
	Y15.4	Cylinder head screw DIN-912-M4x12	0912.04012	S					
	Y16.3	Washer DIN 9021-A 4,3	9021.043	S					
	Y16.4	Washer DIN 9021-A 4,3	9021.043	S					
	Y19.1	Thread pin DIN-916-M4x16	0916.04016		S	S			
	Y19.2	Thread pin DIN-916-M4x16	0916.04016		S	S			
	Y19.3	Thread pin DIN-916-M4x16	0916.04016	S					
	Y19.4	Thread pin DIN-916-M4x16	0916.04016	S					
	Y20.0	Thread pin DIN-916-M4x5	0916.04005		S	S			
	Y20.1	Instep case ISO 8752 2,5x5	8752.02505	S					
	Y20.2	Instep case ISO 8752 2,5x5	8752.02505	S					
	Y21.1	Thread pin DIN-916-M4x5	0916.04005		S	S			
	Y21.2	Thread pin DIN-916-M4x5	0916.04005		S	S			
	Y21.3	Instep case ISO 8752 2,5x5	8752.02505	S					

S = spare part  
W = wear part

## Partlist for MK3 Expl.-Drawing

Group	Pos.	Description	Part.No	80x50	100x80	200x200	Needle group ø3 SerieWS	Needle group ø3 SerieWL	Needle group ø6 SerieWS
	Y21.4	Instep case ISO 8752 2,5x5	8752.02505	S					
	Y22.1	Sicherungsscheibe DIN 6799-10	6799.10		S	S			
	Y22.2	Sicherungsscheibe DIN 6799-10	6799.10		S	S			
	Y22.3	Sicherungsscheibe DIN 6799-7	6799.07	S					
	Y23.1	Sicherungsscheibe DIN 6799-9	6799.09		S	S			
	Y23.2	Sicherungsscheibe DIN 6799-9	6799.09		S	S			